



Remove the panel, and you can find the connector from iDrive knob, either 4 pin or 10 pin. Then, connect them with the 4 pin or 10 pin connectors we provided.

| Car Model | Screen Size | DIP Switches | | | | | | | |
|---------------------------|---------------|--------------|-----|-----|----|-----|-----|-----|-----|
| | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| 1/2/3/4/5/6/7/M3/M4/M5 | 6.5" | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| X1/X2/X3/X4/X5/X6/MINI/Z4 | 8.8" / 10.25" | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |

 Press and hold MENU or BACK button to switch to add-on interface